

### 功率调节

短按 PWR 按键调节功率，长按 PWR 按键进入/退出 PIT 模式

功率表				
PWR LED颜色	绿	红+绿	红	红+蓝
功率	25mW	200mW	500mW	800mW

### 频点调节

短按 FREQ 按键设置频道，长按 FREQ 按键设置频点

FREQUENCY DISPLAY								
FREQ LED	CHANNEL 1	CHANNEL 2	CHANNEL 3	CHANNEL 4	CHANNEL 5	CHANNEL 6	CHANNEL 7	CHANNEL 8
BAND A	BLUE*1, RED*1	BLUE*1, RED*2	BLUE*1, RED*3	BLUE*1, RED*4	BLUE*1, RED*5	BLUE*1, RED*6	BLUE*1, RED*7	BLUE*1, RED*8
BAND B	BLUE*2, RED*1	BLUE*2, RED*2	BLUE*2, RED*3	BLUE*2, RED*4	BLUE*2, RED*5	BLUE*2, RED*6	BLUE*2, RED*7	BLUE*2, RED*8
BAND E	BLUE*3, RED*1	BLUE*3, RED*2	BLUE*3, RED*3	BLUE*3, RED*4	BLUE*3, RED*5	BLUE*3, RED*6	BLUE*3, RED*7	BLUE*3, RED*8
BAND F	BLUE*4, RED*1	BLUE*4, RED*2	BLUE*4, RED*3	BLUE*4, RED*4	BLUE*4, RED*5	BLUE*4, RED*6	BLUE*4, RED*7	BLUE*4, RED*8
RACEBAND	BLUE*5, RED*1	BLUE*5, RED*2	BLUE*5, RED*3	BLUE*5, RED*4	BLUE*5, RED*5	BLUE*5, RED*6	BLUE*5, RED*7	BLUE*5, RED*8
LOWERRACE	BLUE*6, RED*1	BLUE*6, RED*2	BLUE*6, RED*3	BLUE*6, RED*4	BLUE*6, RED*5	BLUE*6, RED*6	BLUE*6, RED*7	BLUE*6, RED*8